

Step 1-1 **Masonry Walls or Cement Walls**

Drill a hole at the marked position with an electric drill and drilling bit.

Note: For a brick-piled masonry wall or cement wall, holes of 10mm diameter and 55mm depth shall be made.

Step 1-1 **Stud Walls**

Note: For a stud wall, holes of 4.5mm diameter and 55mm depth shall be made.

1 Arm

Step 1-2 Remove the cover

Step 1-3 Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

Step 2

1 Arm

Step 1-2 Remove the cover

Step 2 Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

2 Arms

Step 1-2 Remove the cover

Step 1-3 Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

Step 2

2 Arms

Step 1-2 Remove the cover

Step 2 Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

Step 3

Step 4

Step 5

Step 6

Step 7

Step 8

Step 9

Step 10

Tilt (Hinge)

Tilt (Keyboard)

Height Adjust

Rotate

Arm Swing Adjust

Cable Management

Height Adjust

Cable Management

MADE IN TAIWAN