

| STRUCTURE | Silicon Monolithic Integrated Circuit |
|----------------|---------------------------------------------------|
| PRODUCT SERIES | Single-Phase Full-Wave Motor Driver for Fan Motor |
| TYPE | BA6906F |
| FEATURES | Soft switched drive |

OABSOLUTE MAXIMUM RATINGS

| Parameter | Symbol | Limit | Unit |
|--------------------------|--------|----------|------|
| Supply voltage | Vcc | 15 | V |
| Power dissipation | Pd | 780 * | mW |
| Operating temperature | Topr | -40~+100 | °C |
| Storage temperature | Tstg | -55~+150 | °C |
| Output current | lomax | 0.7 * * | А |
| Output voltage | VOUT | 15 | V |
| AL signal output current | IAL | 15 | mA |
| AL signal output voltage | VAL | 15 | V |
| Junction temperature | Tjmax | 150 | ٦° |

* Reduce by 6.24mW/°C over 25°C.

(On 70.0mm × 70.0mm × 1.6mm glass epoxy board)

* * This value is not to exceed Pd.

OOPERATING CONDITIONS

| Parameter | Symbol | Limit | Unit |
|--------------------------------|--------|-----------|------|
| Operating supply voltage range | Vcc | 3.0~14.0 | V |
| Hall input voltage range | VH | 0~Vcc-2.0 | V |

* This product is not designed for production against radioactive rays.

* This document may be strategic data subject to COCOM regulations.



OELECTRICAL CHARACTERISTICS (Unless otherwise specified Ta=25°C,Vcc=5V)

| Parameter | Symbol | | Limit | | 1.1.0.14 | Conditions | |
|-------------------------------------------------------------------|--------|------|-------|------|----------|---------------|--|
| Falameter | Cymbol | Min. | Тур. | Max. | Unit | Conditions | |
| Circuit current | lcc | 1.5 | 3.4 | 8.7 | mA | At output OFF | |
| Charge current of capacitor for lock detection | ILDC | 1.50 | 2.75 | 4.50 | μA | VLD=1.1V | |
| Discharge current of capacitor for lock detection | ILDD | 0.24 | 0.48 | 0.90 | μA | VLD=1.1V | |
| Charge-discharge current ratio of capacitor for lock detection | rCD | 4.2 | 5.7 | 9.5 | - | rCD=ILDC/ILDD | |
| Clamp voltage of capacitor for lock detection | VLDCL | 1.14 | 1.80 | 2.47 | V | | |
| Comparison voltage of capacitor for lock detection | VLDCP | 0.47 | 0.76 | 1.06 | V | | |
| Output voltage L | VOL | - | 0.2 | 0.3 | V | lo=200mA | |
| Output voltage H | VOH | 3.9 | 4.1 | - | V | lo=-200mA | |
| AL terminal voltage L | VALL | - | 0.3 | 0.5 | V | IAL=5mA | |
| AL terminal leak current | IALL | - | 0 | 50 | μA | VAL=15V | |
| Hall input offset voltage | Hofs | -10 | - | 10 | mV | | |
| Hall input—output gain | GHO | 320 | 500 | 680 | - | | |

OPACKAGE OUTLINES



OBLOCK DIAGRAM



OTerminal name

| Pin No. | Terminal | | | | |
|---------|----------|--|--|--|--|
| | name | | | | |
| 1 | OUT2 | | | | |
| 2 | AL | | | | |
| 3 | LD | | | | |
| 4 | Vcc | | | | |
| 5 | H+ | | | | |
| 6 | H- | | | | |
| 7 | OUT1 | | | | |
| 8 | GND | | | | |



OCAUTIONS ON USE

1) Absolute maximum ratings

An excess in the absolute maximum rations, such as supply voltage, temperature range of operating conditions, etc., can break down the devices, thus making impossible to identify breaking mode, such as a short circuit or an open circuit. If any over rated values will expect to exceed the absolute maximum ratings, consider adding circuit protection devices, such as fuses.

2) Connecting the power supply connector backward

Connecting of the power supply in reverse polarity can damage IC. Take precautions when connecting the power supply lines. An external direction diode can be added.

3) Power supply line

Back electromotive force causes regenerated current to power supply line, therefore take a measure such as placing a capacitor between power supply and GND for routing regenerated current. And fully ensure that the capacitor characteristics have no problem before determine a capacitor value. (when applying electrolytic capacitors, capacitance characteristic values are reduced at low temperatures)

4) GND potential

It is possible that the motor output terminal may deflect below GND terminal because of influence by back electromotive force of motor. The potential of GND terminal must be minimum potential in all operating conditions, except that the levels of the motor outputs terminals are under GND level by the back electromotive force of the motor coil. Also ensure that all terminals except GND and motor output terminals do not fall below GND voltage including transient characteristics. Malfunction may possibly occur depending on use condition, environment, and property of individual motor. Please make fully confirmation that no problem is found on operation of IC.

5) Thermal design

Use a thermal design that allows for a sufficient margin in light of the power dissipation(Pd) in actual operating conditions.

- 6) Inter-pin shorts and mounting errors
 - Use caution when positioning the IC for mounting on printed circuit boards. The IC may be damaged if there is any connection error or if pins are shorted together.
- 7) Actions in strong electromagnetic field
 - Use caution when using the IC in the presence of a strong electromagnetic field as doing so may cause the IC to malfunction.
- 8) ASO
 - When using the IC, set the output transistor so that it does not exceed absolute maximum rations or ASO.
- 9) Thermal shut down circuit

The IC incorporates a built-in thermal shutdown circuit (TSD circuit). Operation temperature is 175°C(typ.) and has a hysteresis width of 25°C(typ.). When IC chip temperature rises and TSD circuit works, the output terminal becomes an open state. TSD circuit is designed only to shut the IC off to prevent thermal runaway. It is not designed to protect the IC or guarantee its operation. Do not continue to use the IC after operation this circuit or use the IC in an environment where the operation of this circuit is assumed.

10) Testing on application boards

When testing the IC on an application board, connecting a capacitor to a pin with low impedance subjects the IC to stress. Always discharge capacitors after each process or step. Always turn the IC's power supply off before connecting it to or removing it from a jig or fixture during the inspection process. Ground the IC during assembly steps as an antistatic measure. Use similar precaution when transporting or storing the IC.

11) GND wiring pattern

When using both small signal and large current GND patterns, it is recommended to isolate the two ground patterns, placing a single ground point at the ground potential of application so that the pattern wiring resistance and voltage variations caused by large currents do not cause variations in the small signal ground voltage. Be careful not to change the GND wiring pattern of any external components, either.

12) Capacitor between output and GND

When a large capacitor is connected between output and GND, if Vcc is shorted with 0V or GND for some cause, it is possible that the current charged in the capacitor may flow into the output resulting in destruction. Keep the capacitor between output and GND below 100uF.

13) IC terminal input

When Vcc voltage is not applied to IC, do not apply voltage to each input terminal. When voltage above Vcc or below GND is applied to the input terminal, parasitic element is actuated due to the structure of IC. Operation of parasitic element causes mutual interference between circuits, resulting in malfunction as well as destruction in the last. Do not use in a manner where parasitic element is actuated.

| | copying or reproduction of this document, in part or in whole, is permitted without the asent of ROHM Co.,Ltd. |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The | e content specified herein is subject to change for improvement without notice. |
| "Pr | e content specified herein is for the purpose of introducing ROHM's products (hereinafte oducts"). If you wish to use any such Product, please be sure to refer to the specifications ich can be obtained from ROHM upon request. |
| illu | amples of application circuits, circuit constants and any other information contained herein strate the standard usage and operations of the Products. The peripheral conditions mus taken into account when designing circuits for mass production. |
| Ho | eat care was taken in ensuring the accuracy of the information specified in this document wever, should you incur any damage arising from any inaccuracy or misprint of such prmation, ROHM shall bear no responsibility for such damage. |
| exa imp oth | e technical information specified herein is intended only to show the typical functions of an imples of application circuits for the Products. ROHM does not grant you, explicitly o plicitly, any license to use or exercise intellectual property or other rights held by ROHM and er parties. ROHM shall bear no responsibility whatsoever for any dispute arising from the of such technical information. |
| equ | Products specified in this document are intended to be used with general-use electronic upment or devices (such as audio visual equipment, office-automation equipment, commu ation devices, electronic appliances and amusement devices). |
| The | Products specified in this document are not designed to be radiation tolerant. |
| | ile ROHM always makes efforts to enhance the quality and reliability of its Products, a duct may fail or malfunction for a variety of reasons. |
| aga fail sha | ase be sure to implement in your equipment using the Products safety measures to guard ainst the possibility of physical injury, fire or any other damage caused in the event of the ure of any Product, such as derating, redundancy, fire control and fail-safe designs. ROHM all bear no responsibility whatsoever for your use of any Product outside of the prescribed uppe or not in accordance with the instruction manual. |
| sys ma ins cor of t | e Products are not designed or manufactured to be used with any equipment, device o tem which requires an extremely high level of reliability the failure or malfunction of which y result in a direct threat to human life or create a risk of human injury (such as a medica trument, transportation equipment, aerospace machinery, nuclear-reactor controller, fuel- ntroller or other safety device). ROHM shall bear no responsibility in any way for use of any the Products for the above special purposes. If a Product is intended to be used for any ch special purpose, please contact a ROHM sales representative before purchasing. |
| be | ou intend to export or ship overseas any Product or technology specified herein that ma controlled under the Foreign Exchange and the Foreign Trade Law, you will be required to ain a license or permit under the Law. |



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/