



Note: Contact P/N is for basic contact,  
please add suffix for plating code and,  
for socket contacts, assembly code.

Contact P/N **01412**

**preci-dip**