


PLUGS AND RECEPTACLES

Straight Plug

Part Number	Cable Numbers
050 - 424 - 3188220	RG174/U, 316/U
050 - 424 - 3196220	RG178/U, 196/U




Assembly Instructions

050 - 424 - 3188220 AI 663 (Page 44)
 050 - 424 - 3196220 AI 128 (Page 44)

Right Angle Plug

Part Number	Cable Numbers	A
050 - 428 - 3188220	RG174/U, 316/U	10,16 (.400)
050 - 428 - 3196220	RG178/U, 196/U	9,40 (.370)




Assembly Instructions

050 - 428 - 3188220 AI 286 (Page 45)
 050 - 428 - 3196220 AI 696 (Page 45)

Bulkhead Receptacle - Rear Mount Mounting Nut Outside Panel


Part Number
050 - 443 - 0000220



Mounting Plan U (Page 40)

Bulkhead Receptacle - Front Mount Mounting Nut Inside Panel

Part Number
050 - 445 - 0000220



Mounting Plan U (Page 40)