Staggered jumper; 3-way; insulated; light gray

https://www.wago.com/2002-473







Color: Ight gray

Electrical data

Ratings per IEC/EN	
Nominal voltage (III/3)	400 V
Rated impulse withstand voltage (III / 3)	6 kV
Rated current	25 A

Physical data	
Width	14.2 mm / 0.559 inches
Jumper assignment	1-2-3

Material data	
Note (material data)	
	Information on material specifications can be found here
Color	light gray
Fire load	0.039 MJ
Weight	1.5 g

Environmental requirements

Ziiviioiiiioittai roquiioiito			
Environmental Testing (Environmental Conditions)		Environmental Testing (Environmental Conditions)	
Test specification Railway applications –	DIN EN 50155 (VDE 0115-200):2022-06	Test duration per axis	10 min. 5 h
Rolling stock – Electronic equipment		Test directions	X, Y and Z axes X, Y and Z axes
Test procedure	DIN EN 61373 (VDE 0115-0106):2011-04		X, Y and Z axes
Railway applications – Rolling stock equipment – Shock and vibration tests		Monitoring for contact faults/interruptions	Passed
Spectrum/Installation location	Service life test, Category 1, Class A/B	Voltage drop measurement before and after each axis	Passed
Function test with noise-like vibration	Test passed according to Section 8 of the standard	Simulated service life test through increased levels of noise-like vibration	Test passed according to Section 9 of the standard
Frequency	$f_1 = 5 \text{ Hz to } f_2 = 150 \text{ Hz}$ $f_1 = 5 \text{ Hz to } f_2 = 150 \text{ Hz}$	Extended test scope: Monitoring for contact faults/interruptions	Passed Passed
a 0 a	0.101g (highest test level used for all axes) 0.572g (highest test level used for all axes) 5g (highest test level used for all axes)	Extended test scope: Voltage drop measurement before and after each axis	Passed Passed
		Shock test	Test passed according to Section 10 of the standard

https://www.wago.com/2002-473



Environmental Testing (Environmental Conditions)

Shock form Half sine
Shock duration 30 ms

Number of shocks per axis 3 pos. und 3 neg.

Vibration and shock stress for rolling

stock equipment

Passed

Commercial data	
Product Group	22 (TOPJOB S)
PU (SPU)	25 pcs
Packaging type	Bag
Country of origin	DE
GTIN	4055143692267
Customs tariff number	85366990990

Product classification

UNSPSC 39121410

Environmental Product Compliance

RoHS Compliance Status Compliant, No Exemption

Approvals / Certificates

Declarations of conformity and manufacturer's declarations



Approval Standard Certificate Name

Railway - Railway Ready

WAGO GmbH & Co. KG

Downloads

Environmental Product Compliance

Compliance Search

Environmental Product Compliance 2002-473



Documentation

Bid Text			
2002-473	19.02.2019	xml 2.62 KB	$\underline{\downarrow}$
2002-473	27.04.2017	doc 24.00 KB	$\underline{\downarrow}$

https://www.wago.com/2002-473



CAD/CAE-Data CAD data 2D/3D Models 2002-473 WSCAD Universe 2002-473 ZUKEN Portal 2002-473 LUKEN Portal 2002-473

Installation Notes

Commoning





Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push down until it hits the backstop.

Commoning two potentials in one single jumper slot via extremely slim staggered jumpers.


Commoning



Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push down until it hits the backstop.

Commoning



Removing a staggered jumper: Insert the operating tool between the staggered jumpers, then lift up the jumper.

https://www.wago.com/2002-473



Commoning



Staggered jumper (seven contacts)Breaking off contact lugs. Individual jumper contacts can be broken off by bending them. The remaining piece of insulation will meet requirements for clearances and creepage distances.



Staggered jumpers Marking with a felt-tip pen.



Staggering jumpers in a single jumper slot:

Custom staggered jumpers can be created, e.g., for bridging over a terminal block with a different potential. Make sure that only one contact lug is in contact with the terminal block.

The contact lugs of the customized staggered jumpers contact the terminal blocks via the gaps created in the second jumper. Insert and press the ready-made jumper assembly into the jumper slot until it hits the backstop.

Subject to changes. Please also observe the further product documentation!

Current addresses can be found at:: www.wago.com